



NOTE:  
TAPS IN STAGGERED  
CONFIGURATION AT  
10 O'CLOCK OR  
2 O'CLOCK POSITION.

- NOTES:
1. CONTINUE PIPE LAYING AT THE SAME ALIGNMENT AND GRADE THROUGH THE MANHOLE AND INSTALL AN INLINE WYE FITTING AT 10 O'CLOCK OR 2 O'CLOCK POSITION. INSTALL PLUG AT WYE FITTING OR USE THE ALTERNATE METHOD OF A PIPE STUB AND CAP.
  2. CUT AND REMOVE P.V.C. PIPE IN MANHOLE FROM SPRINGLINE TO TOP OF PIPE AND GROUT EDGES OF CUT PIPE TO INVERT AFTER THE BASE HAS BEEN POURED AND CONCRETE HAS SET.
  3. ONLY ONE SERVICE CONNECTION IS ALLOWED PER MANHOLE.
  4. USE IN CONJUNCTION WITH THE STANDARD MANHOLE DETAIL.

DATE  
10/2007

DRAWING  
D.27S

SOUTHWEST METROPOLITAN  
WATER & SANITATION DISTRICT

SERVICE CONNECTION  
TO  
DEAD-END MANHOLE